

ENGLISH


Thank you for choosing Esseci

SCMQ10A-x1000

UK

Master Qbo with MODBus serial port to command up to 16 serial slave units.  
Suitable to manage heating or evaporative cooling or wine making installation.

WIRING DIAGRAM



WIRING DIAGRAM

POWER SUPPLY	
1 - 2	SCMQ10A-B1000: Power supply 12Vac/dc
ALARM OUTPUT	
3 - 4 - 5	Alarm relay 1A 24Vac
PROBES	
C - P1	(C) Common of sensor, (P1) global temperature sensor 1.
C - P2	(C) Common of sensor, (P2) global temperature sensor 2.
C - P3	(C) Common of sensor, (P3) outside temperature sensor.
SCBus Qbo SERIAL CONNECTION	
+A, -B, S	SLAVE : SCBus RS 485 serial connection to the slave modules
MODBus SERIAL CONNECTION	
+A, -B, S	SUPERVISOR : RS485 MODBus network connection to a SCADA or supervisor.
SWITCHES	
TR	End of line resistor

SCMQ10A-F1000 = SCMQ10A-B1000 + SCAPW30W-110 built inside the box

POWER SUPPLY INPUT : J1A: power supply input 120 / 230Vac +/-10%

POWER OUT : J2 12Vdc output. Connect J2 to the terminals 1 and 2 of the SCMQ10


F1: 5x20mm fuse, value 1AT.

LD1: status led of the SCAPW30.

- On : SCAPW30 under power supply;

Off : SCAPW30 without power supply.

POWER SUPPLY INPUT : J1A: power supply input 120 / 230Vac +/-10%



- Avoid crossing cables by separating ELV ExtraLowVoltage from load-referred connections.
- Protect the device power supply and probe inputs from electric disturbances.
- Disconnect the appliance from the power supply before carrying out any maintenance;
- Do not EVER open the device plastic enclosure

2. TECHNICAL FEATURES

Power supply:	SCMQ30A-B1000: 12Vac/dc +/-10%. use only SELV power supply with a 315mA slow-blow fuse on the secondary. Only for SCMQ30A-F1000: 120/230Vac with SCAPW30W-110 device built inside the box.
Insulation guaranteed by the power supply	For 230V: Insulation from very low voltage parts : reinforced. Insulation from relay output : reinforced.
Operation field:	For 12Vac-dc: use only a safety isolating transformer (SELV) -50.0...150°C
PTC 990Ω accuracy:	-2 °C nel range -60T50 °C; ~5 °C nel range +50T160 °C;
Unit consumption:	5W
Housing:	plastic enclosure 180 x 150 x 65mm
Fixing:	on wall
Data storage:	on EEPROM memory
Front protection:	IP44
Employment conditions:	environment temperature 10...40°C storage temperature 0...60°C
Relative environment hum:	30 / 80%, without condensation
Connection:	screw terminal, cables max cross section 2,5mm²
Display:	LCD display
Inputs:	1 input for PTC 990 Ω @25°C (if enabled)
Outputs:	1 relay ALARM SPDT 1A 24Vac
Insulation guaranteed by the output	Insulation from very low voltage parts : reinforced;
Serial Connections:	2 serial port RS-485: - SLAVE: to SCBus iNET. 1.000m max length tolerated for the network; - SUPERVISOR: to MODBus. 1 iFS serial interface TTL to the expansion key: • device firmware update; • quick arameter setting (copy/paste);

3. MAIN FEATURES

SCBUS AND INFRANet, 2-WIRE BUS CONNECTION: A two-pole cable is required to connect the master to the zone slave modules. This simplifies the connection.

The two-way communication runs along a RS-485 serial line made of a 2-wire twisted shielded cable (i.e. Belden 8762 with PVC sheathing 2 twisted terminals + copper sheathing, 20 AWG, 89pF cables nominal capacity, 161pF cable / copper sheathing nominal capacity). 1.000m max length tolerated for the network;  
LCD DISPLAY: a large LCD display helps to keep the thermostat always under control at a glance. Scrolling text messages and symbols describe the operations in progress. The display decimal range is: -50,0 and 999,0, out of this range the device switches automatically to integer numbers.

4. MODBUS

MODBus communication enabled in write/read mode only if H0r= 0, in this case the icon is on. Through this parameter you enable/disable the MODBus connection, BMS, and the possibility to change the parameters of the devices only by MODBus or by SCMQ10 keyboard. Especially if H0r is:

0 = the MODbus is always enabled, change of the parameters of the devices are allowed only by MODBus, you can not change them by SCMQ10, with the exclusion of the parameters Lrn, rSt or H0r;  
NOTE: if H0r = 0 the value of the Modbus register n°141 tells to the SCMQ10 if the BMS is connected or not. The value of the index n°141 is the time, expressed in seconds, after which the connection to the BMS is no longer considered active, the SCMQ10 shows an alarm A 62 and the A-M parameter of all the network devices connected to the terminal SCMQ10 is automatically fixed to oFF. When the value of the index n°141 becomes ≠ 0, BMS connected, the BMS must set again the A-M value of all the network devices, if different from oFF.  
To avoid this alarm write cyclically, before it expires, the value of the BMS time-out on the index 141.  
For example: if you want that the BMS connection becomes invalid after 10 minutes, 600 seconds, write 600 on the index 141 at least every 5minutes / 300 seconds

1 = MODBus always disabled. Change of the parameters of the devices are allowed only by SCMQ10, anyway you can read the parameters both by SCMQ10 and MODBus;

For the MODBus parameters of the terminal SCMQ10 see datasheet E13130.

FIRST START

5. SCMQ10, FIRST START:  
- CLOCK / CALENDAR SETUP;  
- ACQUISITION OF THE ZONE MODULES;

NOTE: BEFORE POWER ON THE SCMQ10 FOR THE FIRST TIME CHECK:  
- WHEN CONNECTING THE TERMINAL SCMQ10 TO THE SERIAL DEVICES, see "SCBus network connection"; DO NOT SWAP +A / -B WIRES.  
- MAKE A LINEAR NETWORK CONNECTION: NOT STAR, RING OR TREE.  
- MAKE SURE THE REMOTE CONTROLS ARE CONNECTED AND SUPPLIED, BEFORE PROCEEDING.  
- CONNECT MAX 16 ZONE MODULES TO THE SCMQ10. ADDRESSES FROM 0 TO 15.

At the SCMQ10 first start up the master device shows for ~5s. the clock, for ex.: 8:10, Monday. (1 = Monday; 2 = Tuesday;...7 = Sunday).



If the clock is not correct set it correctly. To change/set the clock and the calendar see the paragraph n° 5.1 : CLOCK / CALENDAR SETUP.

Should the device lack of a previously acquired network, an acquiring process will automatically after the clock visualization i.e. at the SCMQ10 start up. Now the SCMQ10 shows the Lrn label.  
At the end, the display shows the list of the acquired devices:



QUICK GUIDE	Point
<b>MASTER SCMQ10: INSTALLATION</b>	
• Warnings	1
• Technical features	2
• MODBus	4
<b>FIRST START</b>	
• SCMQ10 first start:	5
- clock / calendar setup;	5.1;
- acquisition of the zone modules.	5.2;
<b>USE</b>	
• SCMQ10 front panel:	6
- keypad;	6.1;
- display: icons and symbols;	6.2;
- menu / parameters setup;	6.3;
- lock / unlock SCMQ10 keypad;	6.4;
• On / off, stand-by of the zone module.	7
• Set-point of the zone module.	8
• Automatic-manual operation mode of the zone module:	9
- Timer programs of the zone module;	9.1;
• Menu list of the zone module;	10
• Menu list and parameters of the SCMQ10 master	11
• Alarms and display warnings	12
• Burner reset	13

MASTER SCMQ10: INSTALLATION

1. WARNINGS

BEFORE OPERATING ON THE DEVICE, PLEASE CAREFULLY READ THE INSTRUCTIONS IN THIS MANUAL. KEEP THIS MANUAL IN A SAFE PLACE FOR FUTURE REFERENCE

Use the appliance only for its intended purpose as described in this manual. The Manufacturer declines all responsibility for inappropriate use or incorrect setting of the controls. To ensure safe operation:

- Appliance must be properly installed and maintenance must be performed according to this manual;
- Supply voltage and environmental conditions fall within the values specified on appliance data plate.

ELECTRIC CONNECTIONS

THE DEVICE IS NOT PROTECTED AGAINST CIRCUIT OVERLOADING: EQUIP POWER SUPPLY INPUT AND ALL OUTPUTS WITH NECESSARY SAFETY DEVICES.

**ZONE NUMBER**

00:01:15

Acquired / acknowledged device

⚠ + **error 32** (point n°12) Acquisition failed: too many modules connected to the master.

⚠ + **error 11** (point n°12) Acquisition failed: no modules connected to the master. Error When the network has been created the SCMQ10 shows the first zone module.

You can scroll the thermal zones by using the keys or .

The master SCMQ10 cyclically shows the different zones, every 15s., only if the parameter **H8=YES**.

To repeat the acquisition of the zone modules see the following paragraph: 5.2 ACQUISITION OF THE ZONE MODULES.

**5.1 CLOCK / CALENDAR SETUP**

To **adjust** the current date and time showed on display, proceed as follows:

- press the key for ~1s. until the hour digits start to flash;
- press or to set the current hour;
- press to confirm it; the minute digits flash;
- press or to set the current minutes;
- press to confirm it; the set day flashes;
- press or to set the current day, ex:  

DAY 1	DAY 2	DAY	6	DAY	7
1= Monday	2= Tuesday	6= Saturday		7= Sunday	
- press to confirm it; the year "400" flashes;
- press or to set the current year;
- press to confirm it; the month "10" flashes;
- press or to set the current month;
- press to confirm it; the day of the month "10" flashes;
- press or to set the current day of the month;
- press to confirm it;
- to exit the clock setting and came back to the normal functioning of the SCMQ10 press or wait **H0d** s. without touching any key.

**5.2 ACQUISITION OF THE ZONE MODULES**

To start the acquiring process, go to parameter **Lrn** of the master **SCMQ10**, see point 11.

Set **Lrn** to **YES** and press to start the network acquisition.

**MASTER SCMQ10: USE**

**6. SCMQ10 FRONT PANEL**



**NOTE:** the SCMQ10 automatically reduces the display brightness if you do not act on the keyboard for 10s. (See the parameter **Li9** paragraph n°6.3)

Press any key to light it again.

**6.1 KEYBOARD**

- Pon** **ON/OFF** - press it for 1s.: to enter the On / Off (stand-by) function of the zone module displayed on the **ZONE NUMBER** area.
- SET POINT** - press it for 1s.: to enter the set-point of the zone module displayed on the **ZONE NUMBER** area.
- AUTOMATIC / MANUAL / TIMER PROGRAMS** - press it for 1s.: to enter the automatic / manual function of the zone module displayed on the **ZONE NUMBER** area. To enter the timer programs of the zone module set **AUTO** and press ENTER.
- ESC / RESET:**
  - + if hold it to enter the reset parameter of the zone module displayed on the **ZONE NUMBER** area (ONLY for heating devices with RESET function).
  - + in setup mode it works as ESC / RETURN.
- ENTER:** it works as ENTER/CONFIRM button. Press it :
  - + to enter the displayed menu/parameters;
  - + to confirm / start the displayed functions.
- UP:** press it:
  - + if it scrolls the available zone modules;
  - + in setup mode to increase the display value;
  - Hold it with the **DOWN** key for ~5s.. to temporarily unlock the keyboard if locked;
- DOWN:** press it:
  - + if it scrolls the available zone modules;
  - + in setup mode to decrease the display value;
  - Hold it with the **UP** key for ~5s.. to temporarily unlock the keyboard if locked
- MENU:**
  - if press it to enter the menu list of the zone module displayed on the **ZONE NUMBER** area;

**6.2 DISPLAY: ICONS & SYMBOLS**

**ZONE NUMBER** This area shows the address of the zone module on display. Ex.: =zone module n°3.

**MASTER Terminal device SCMQ30**

**On/Off - zone module status:** shows if the zone module on display is enabled or disabled:  
 Zone module Off mode. it is not a power cut off, it is rather a STAND BY mode. The controller keeps powered in Off mode. The zone module in off mode does not maintain the reduced set-point. The SCMQ30 display shows only the zone number and the **OFF** label.  
 Zone module ON.

	<b>Summer:</b> zone module in summer/cool mode. (direct action).
	<b>Winter:</b> zone module in winter/heat mode. (reverse action).
	<b>Temperature alarm:</b> temperature alarm in progress; no temperature alarm.
<b>EA</b>	<b>Generic alarm:</b> EA alarm in progress for the zone module displayed. If the code of the zone module is: - SCQP30: thermal overload alarm; - SCRE55: float alarm; - SCRW12 : door switch alarm; no EA alarm for the zone module displayed.
<b>EA2</b>	<b>Generic alarm 2:</b> AG2 alarm in progress for the zone module displayed. If the code of the zone module is: - SCQP30: gas pressure alarm; - SCRW12 : level alarm; no AG2 alarm for the zone module displayed.
<b>SEA</b>	<b>External several alarm.</b> SEA alarm in progress for the zone module displayed. If the code of the zone module is: - SCRW12: EA or EA2 alarm with stop of the regulation; no SEA alarm for the zone module displayed.
	<b>Home - home page.</b> home page of the displayed zone module: the display shows the quantity/temperature of the displayed zone; access to the menus / parameters of the zone module on display.
	<b>LOAD</b> - status of the "water load" of the displayed evaporative cooler. tank filling, water load in progress; no water load;
	<b>DUMP</b> - status of the "water dump" of the displayed evaporative cooler. tank drain, water dump in progress; no water dump;
	<b>PUMP</b> - status of the "pump" of the displayed evaporative cooler or wine maker.. pump working: water flowing, pads wetting; if blinking: free cooling in progress; (only for evaporative cooler) pump off;
	<b>Float n° 1:</b> full tank, load water off, pump enable; tank not full;
	<b>Float n° 2:</b> minimum level of the tank; tank empty, pump off, water load enable;
	<b>BMS - MODBus connection:</b> connection available and operative, <b>H0r = 0</b> , change to the parameters of the devices are allowed only by MODBus. From SCMQ10 you can only read the value of the parameters; if blinking: connection available and not operative. Change to the parameters of the devices are allowed by SCMQ10. <b>H0r = 1</b> and modbus index n°141 > 0; MODBus connection not available, <b>H0r = 1</b> and modbus index n°141 = 0, change to the parameters of the devices are allowed only by SCMQ10;
	<b>Global zone 1:</b> zone module displayed subjected to the global zone 1;
	<b>Global zone 2:</b> zone module displayed subjected to the global zone 2;
	<b>ALARM:</b> Icon on: alarm in progress for the zone module displayed. Enter to the alarm list to see the code of the alarm in progress.
	<b>Configuration Setup:</b> Setting mode, if the configuration icon: - is on when the display shows the parameter/menu label; - blinks when the display shows the parameter value;
	<b>Day of the week:</b> = Monday, ... ,  = Sunday .
	<b>Zone module ON.</b> For zone modules of heating means burner/s on with <b>SP1C</b> temperature. For evaporative coolers: refers to timer programs of COOL mode.
	<b>Zone module ON.</b> For zone modules of heating means burner/s on with <b>SP1E</b> temperature. For evaporative coolers: refers to timer programs of FAN mode.
	<b>Zone module in stand-by / OFF.</b> For zone modules of heating means burner/s off, the burner maintains just the frost protection set-point. If <b>r=0</b> no frost protection setpoint, burner outputs OFF. For evaporative coolers: means that the evaporative cooler is in stand-by,
	<b>Manual mode:</b> Icon on: zone module on display in manual mode; Icon off: zone module on display in automatic mode;
	According to the type of application of zone module displayed. <b>FAN</b> , if the icon is on it means: - for heating: fan output on; . - for evaporative coolers: evaporative cooler is working in fan mode.
	<b>Burner output for heating.</b> If the icon is: - on = burner output on or first stage on in the case of a multi-stage burner; - blinking = functioning light of burner ON or 1 <sup>st</sup> level ON;
	<b>Burner output - 2<sup>nd</sup> level of flame.</b> If the icon is: - on = second stage burner output on; - blinking = functioning light of the 2 <sup>nd</sup> level ON;
	According to the type of application of the zone module displayed <b>COOL</b> for evaporative coolers. If the icon is on the evaporative cooler is working in cool mode.
<b>BLK</b>	<b>Burner in lockout.</b> for heating. If the icon is on the controller detects a flame failure in the zone.

### 6.3 MENU / PARAMETERS SETUP

The menus and the parameters of the SCMQ10 terminal and of the zone modules are in folders.

To access to menus and parameters of the displayed zone module:

- make sure you are in the desired module home page, ;
- press briefly , when you release the key the symbol switches off, the symbol switches on and the display shows the first menu of the module;
- press or to scroll the menu, a short description will be shown at the bottom of the display, i.e.: "tiME - clock menu";
- press to open the selected menu; the display shows the first parameter and the setup icon light is on;
- press or to scroll the parameter list. A short description will be shown at the bottom of the display;
- press : the display shows for 5s the parameter value and the symbol blinks. If the icon remains on together with the icon you will only read the value of the parameters, if you want to change them from the Qbo terminal set the parameter  $H0r = 1$ ;
- press or to change the value;
- press to confirm the value and go back to the parameter list;
- to exit and save changes either press or wait for 30 seconds until the symbol switches on, .

**NOTE:**  $H0d$  is the max permanence time into the module setting procedure.  
The setup symbol keeps lit steady when scrolling the parameter list. It blinks when displaying the parameter value.

### 6.4 SCMQ10 KEYPAD LOCK & UNLOCK

To lock the SCMQ10 keypad, set  $HL=4ES$ .

With the keypad locked, the following operations are NOT allowed:

- switching ON/OFF of the zone module;
  - access to the set-point of the zone module;
  - access to the automatic/manual function of the zone module;
  - access to all parameters/menu of the zone module;
  - selecting the zone to display.
- resetting burners

When the keypad is locked, the message  $LOC$  will be displayed anytime a key is pressed.

To temporarily unlock the keypad hold and for at least 3s. until the message  $UnL$  is displayed. The keypad re-locks automatically after 15s. of inactivity.

### 7. ON / OFF STAND-BY OF THE ZONE MODULE

To switch the displayed zone module ON/OFF hold the key until the  $P-on$  message is displayed. Release the pressed key, now the display shows the set value for ~5s..:

- 1 : zone module ON,
- 0 : zone module OFF,

**ATTENTION:** the zone module keeps powered even when in off / stand-by mode.

When the zone module is in OFF mode, the display of the SCMQ10 shows the message  $OFF$ . No antifrost setpoint is maintained in this mode.

To change the displayed value press or , then press to confirm the value and go back to the parameter.

The menu  $Fnc$  includes the  $P-on$  parameter.

### 8. SET-POINT OF THE ZONE MODULE

To locate and set the set-point of the zone module displayed hold the key until the  $SP ic$  or  $SP$  message is displayed. Release the pressed key, now the display shows the set value for ~5s..:

To change the displayed value press or , then press to confirm the value and go back to the parameter.

The menu  $SEt$  includes the  $SP ic$  or  $SP$  parameter.

### 9. AUTOMATIC-MANUAL OPERATION MODE OF THE ZONE MODULE - TIMER PROGRAMS OF THE ZONE MODULE

To locate and set the operation mode of the zone module displayed hold the key until the  $A-N$  message is displayed. Release the pressed key, now the display shows the set value for ~5s..

According to the type of application of the zone module:

+ for heating, radiant panels, warm air generators:

- $OFF$  the zone module is in Manual OFF mode. Burners are off, they just maintain the frost protection setpoint if  $rt > 0$ ;
- $Auto$  the zone module is in Automatic mode. Burners activate according to the set timer programs;
- $on-L$  the zone module is in Manual ON mode. Burners just maintain the COMFORT set-point,  $SP1C$ .
- $on-E$  the zone module is in Manual ON mode. Burners just maintain the ECONOMY set-point,  $SP1E$ . (Only if  $r0=2$ ).

+ for evaporative cooling:

- $OFF$ : the zone module is in Manual OFF mode, disabled;
- $Auto$ : the zone module is in Automatic mode. It activates according to the set timer programs;
- $COOL$ : the zone module is in Manual Cooling mode;
- $FAN$ : the zone module is in Manual Fan mode.

To change the displayed value press or , then press to confirm the value and go back to the parameter.

**NOTE:** set  $Auto$  to access the timer programs of the zone module.

The menu  $Fnc$  includes the  $A-N$  parameter.

### 9.1 TIMER PROGRAMS OF THE ZONE MODULE

A timer program is a command of zone module ON / OFF. The zone module sorts them by day and time and runs them cyclically.

Each zone module for heating and for evaporative cooling has its specific timer programs, up to 28 different programs a zone. The zone module executes them only if  $A-N = Auto$ . Timer is overridden:

- by ON / OFF manual function;
- by switching OFF the zone module, ;
- by the zone probe key selector, if available.

To **access** to the timer programs set  $A-N = Auto$  and press

- the display shows the first timer program set for the selected zone. The display shows the message " - - - " in case no timer programs are set.

**NOTE:** if the master terminal has the network timer programs enabled,  $PtE = YES$ , and the network device has a global probe and  $t8 = no$  then you enter the network timers of the relative global zone.

To **scroll** the set timer programs or locate the first free place of memory press the button. The first free place of memory is signalled as " - - - ".

To **set / change** the timer program displayed press for ~5s.. until the digits of hours of the timer program and blink;

- press or to select the starting hour of the timer program;
- press to confirm the value; the digits of minutes blink;
- press or to select the minutes, they move forward / backward by 10;
- press to confirm the value; the signal of the day blinks, for example  $[1]$ ;
- press or to select the day when the timer program should be active, i.e.:  
 $[1]$  = Monday  $[2]$  = Tuesday  $[7]$  = Sunday

- press to confirm the value. The timer program type will be displayed:

+ for heating zone module:

- o icon +  $on-L$  = it is a timer program of outputs ON with comfort set-point.  
If  $H-C=HEAT$ , reverse action/winter: it is a program of burner ON with SP1C.  
If  $H-C=COOL$ , direct action/summer: it is a program of fan ON (depending on models);
- o icon +  $on-E$  = it is a timer program of outputs ON with economy set-point, only if  $r0=2$ .  
If  $H-C=HEAT$ , reverse action/winter: it is a program of burner ON with SP1E.  
If  $H-C=COOL$ , direct action/summer: it is a program of fan ON (depending on models);  
NOTE: when you add new timer programs of economy set-point,  $r0=2$ , and then you set  $r0=1$  all SP1E timer programs will be automatically executed as timer programs with SP1C;
- o icon +  $OFF$  = it is a program of output OFF with frost protection set point.  
If  $H-C=HEAT$ , reverse action/winter: it is a program of burner OFF with frost protection set point, only if  $rt \neq 0$ .  
If  $H-C=COOL$ , direct action/summer: it is a program of fan OFF. (depending on models)

+ for evaporative cooler zone module with  $H-C=COOL$ :

- o icon +  $COOL$  =  $COOL$ , it is a timer program of cooling;
- o icon +  $FAN$  =  $FAN$ , it is a timer program of fan;
- o icon +  $OFF$  =  $OFF$ , it is a timer program of output off.

To **delete ONE** or **ALL** selected timer programs go to the timer program menu as described in the previous paragraph;

- To delete ONE program:

- o press to select the scheduled timer program to be cancelled
- o hold for 3s until " - - - " will be displayed.

- To delete ALL the saved TIMER programs hold for 6s until "EALL" will be displayed.

To **exit** the timer program menu wait for 10s.

### 10. MENU LIST OF THE ZONE MODULE

To access to the menus of the displayed zone module, proceed as follows:

Make sure you are in the thermostat home page, .

- To scroll the different heating zones press or , see the **ZONE NUMBER** area:

- press briefly , when you release the key the symbol switches off and the display shows the first menu of the list, i.e.:  $SEt$ , set-point menu.



To access/change the parameters of a menu of the displayed zone module proceed as described at the paragraph 6.3.

The menus of the zone module are: (according to the network module)

-  $AL SE$ : alarms menu.

The menu includes the list of the alarms in progress. For more information read the paragraph n°12. This menu appears only if there is an alarm on the network.

-  $SEt$ : set-point menu:

Set-point is the temperature or the regulation value of the zone module. According to the application of the zone module the menu includes the following parameters:

Zone modules for heating:

- o  $SP1C$  = comfort set-point;
- o  $SP1E$  = economy set-point (only if  $r0=2$ );

Zone modules for evaporative cooler:

- o  $SP$  = temperature set-point;
- o  $RU$  = humidity set-point. When the environment humidity exceeds the  $RU$  setpoint, the evaporative cooler pump stops.

-  $Fnc$ : functions menu.

According to the application of the zone module the menu includes the following info:

- o  $P-on$  = zone module on/off. If the value is:  
+ 1 : zone module ON,



- HH3: display release firmware;
- HH3b: build of HH3;

Hold together ~5s.. the and buttons to go to the list of the keyboard functions directly.:

#### - Lrn: acquisition of the zone modules;

To start the acquiring process, go to parameter *Lrn*;

Set *Lrn* to *YES* and press to start the network acquisition.

## 12. ALARMS AND DISPLAY WARNINGS

In case of alarm / failure the display of the Qbo terminal shows the message " ALARM ".

If the display shows the message and the symbol it means that the zone module / terminal on display is in alarm.

Press briefly the key now the display shows the alarms menu. *ALSt*, to enter and read the list of pending alarm events proceed as described at point 6.3. I.e.: the image on the right means that the zone n°24 is not connected to the SCMQ10.

To exit either press the button or wait for *H0d* s..

**NOTE:** When an alarm occurs, if it is not cleared within 4 minutes, the master unit SCMQ10 activates the alarm relay.

*ALSt* alarm menu is only available and accessible when an alarm / error event occurs.

The alarm menu collect up to 5 alarm events for every zone module and also 5 alarm events for the Qbo terminal.

### ALARM / ERROR CODES

Cod.	Description
A 1	<b>BLK</b> : Burner in lockout.
A 10	Eeprom SCMQ30 master broken, switch the thermostat off and on again Eeprom SLAVE MODULE broken, switch the thermostat off and on again
A 11	<i>no n</i> Network error. SCMQ30 without network, network not acquired.
A 12	Network error: network device disconnected or not connected.
A 13	Clock error. Check and set the date and time
A 14	Failure in the network probe setting. Check and correct the parameters <i>/P1</i> and <i>/P2</i> . NOTE: the error happens also if <i>/P1 = /P2 = 0, 1, 2, ..., 15</i> .
A 15	Error of Master: network failure. Repeat the network acquisition procedure: it may occur when you replace a network slave module with one having the same serial address.
A 16	<b>SEA</b> : Several alarm
A 17	<b>EA</b> : Evaporative cooler module: float alarm, error tank filling/drainage
A 18	<b>EA2</b> : Generic alarm 2
A 19	<b>EA</b> : Generic alarm
A 20	Fault of probe 1.
A 21	Fault of probe 2 (If available)
A 22	Fault of probe 3 (If available)
A 23	Fault of probe 4 (If available)
A 24	Fault of probe 5 (If available)
A 25	Fault of probe 6 (If available)
A 28	Fault of outside probe (If available).
A 32	<i>o-n</i> Network acquisition error. Too many modules connected to the master SCMQ30
A 35	Serial error. The serial number of the SCMQ30 in the memory is damaged.
A 38	High humidity alarm
A 39	Low humidity alarm
A 40	hot / cold - Zone module temperature alarm
A 41	hot / cold - Zone module high temperature alarm. <b>SEA</b> : overheat alarm
A 42	hot / cold - Zone module low temperature alarm.
A 43	Zone module high fumes temperature alarm - P2
A 45	Zone module high fumes gas temperature alarm - P3
A 50	Zone module door switch
A 51	Zone module limit level
A 52	Error communication igniter
A 53	Error communication inverter 1
A 54	Pump alarm. (for wine maker device)
A 55	Chiller alarm. (for wine maker device)
A 62	BMS not connected. If the <b>A 62</b> alarm is in progress the <b>A-M</b> parameter of all the network devices connected to the terminal SCMQ10 is automatically fixed to <b>oFF</b>
A 63	Network device communication error
A 64	Global timer configuration wrong; check the value of the parameters <b>PIE</b> of the SCMQ30 or <b>t8</b> of the network devices
A 66	Digital input inverter alarm
A 69	<b>EAP</b> : Evaporative cooler module: Pressure switch alarm
A 70	<b>EEI</b> : Evaporative cooler module: Communication error between the devices
A 98	Memory of the counters corrupted, erase the values of the counters Cn-1 and Cn-2
A 99	The thermostat resets more than 5 times within 15min.
A100	Time based maintenance.
A199	New lan acquired different from the previous
A240	Volatile burner lockout

## 13. BURNER RESET

Function only available for the zone modules featuring the reset command.

- Press / to select the desired zone module;

- hold the key pressed until the display shows *rSt*;

- release the key, now the display shows the value *00*;

- press to set the parameter to *0 1*;

- to execute the burner reset press or wait 3s. without pressing any key;

Should the alarm menu shows the alarm **A 99**, it means that the reset is locked, if you exceed the 5 attempts within 15min. then the burner command locks. Set **H30 = 1** to unlock the reset command.

## 14. GUARANTEE

Warranty on materials: 1 year (from production date, excluding consumables). The Company shall only repair or replace products, which are found to be defective after inspection by EsseCI's technical service. The Company shall not be under any liability and gives no warranty in the event of defects due to exceptional conditions of use, misuse or tampering. All warranty claims returned to EsseCI must have prior return authorization. Customer will be responsible for all return shipping charges and fees.

## 15. DISPOSAL



The device must be disposed of in compliance with local standards regarding the collection of electric and electronic equipment.

## 16. NOTES

The present publication copyright is exclusive property of EsseCI Srl. It is forbidden to reproduce or transmit it or parts of it unless expressly authorized. The information contained in the present publication is subject to changes without notice and does not have any binding effect on EsseCI Srl. All other uses and modifications made to the device that are not authorized by the manufacturer are considered incorrect. Liability for injury or damage caused by the incorrect use of the device lies exclusively with the user even if EsseCI or its subsidiaries are warned of the possibility of damage.



EsseCI Srl  
Via degli Alpini 5 – 31047 PONTE DI P. (TV) - ITALY  
Tel. +39(0)422-854657 - Fax +39(0)422-854665